

How to install cable lock into a firearm

Make sure ALL firearms are UNLOADED before they are put away.



SEMI AUTOMATIC PISTOLS: remove the magazine, and with the slide back, insert the cable part through the ejection port and out of the magazine well.



SEMI AUTOMATIC or PUMP- ACTION SHOT FIREARMS: put the bolt in the open position and insert the cable part through the ejection port and out of the loading port.



REVOLVERS: open the cylinder and insert the cable part through the barrel or through an empty chamber.



BOLT ACTION RIFLES: open the action or remove the bolt from the rifle. Then remove the magazine and insert the cable through the ejection port and out of the magazine well or the receiver assembly.



MODERN SPORTING RIFLE: With the charging handle and bolt locked back and the magazine removed, insert the cable through the ejection port and out the magazine well.

This cable lock can be used with many different firearms.

